Contains: 1 Cable modem, 1 Ethernet cable, 1 AC Power cord (output 12V/1.5A).

Connection Guide

1. Connect coaxial cable from wall coaxial cable jack to coaxial jack in the modem.
2. Connect AC Power Cord

After few minutes of waiting on signal, **Power, Down Stream, Up Stream and Online must be steady on.** If any of top 4 lights are missing or flashing, please contact us at support@gtatel.com for further assistance.

Please note: Link may off, flash or solid depending on the status of your router connection or activity.